

Directions for Designer Bench



1. Stand up the legs and align with the predrilled holes in the bench
2. Make sure the bench side with the larger hole is face up and drill a pilot hole where you wish to position the bench.
3. Insert lag screws and washers. Use a socket drive to tighten into the pilot holes
4. If you purchased an anchor kit, then open that now and drill pilot holes into the leg through the top hole in the bracket. Insert lag screws.
5. Drill pilot holes into cement through the bracket and fit the steel insert into the concrete. Screw in bolt through bracket into steel insert.