

PT-8 Instructions

fig1



1)

Begin by standing up the legs on a flat level surface and then setting the table top over the legs and in line with the pre-drilled screw holes (fig 1). Anchor each corner with a screw (fig 2) and use a level to ensure the legs are straight before continuing. You can also start out by putting on the benches first, just make sure that the legs are straight.



fig2

2)

Fasten the braces to the underside of the table and to the legs. Make sure to use the double cut side in the middle of the table and the single cut side to the inside of the table legs (fig 3)



fig3

3) Now you are ready to align the benches on each side and screw into place. Make sure the legs are touching the “stop board” on the underside of the bench. Double check all areas to ensure all screws are fastened.



Engineered Plastic Systems, LLC
885 Church Rd
Elgin, IL 60123-9309
P:847.289.8383 F:847.289.8382
www.EPSPlasticLumber.com