

# SPT8- H2

## Double Overhang Accessible



1) Insert carriage bolts into the pre-drilled holes on the top of the table. Tap into place with non-marring hammer. (You may want to run a piece of Duct tape over them to hold them into place until final assembly.)

2) Flip table over. Line up the table legs over bolts and fasten with nuts. Make sure to face the EPS stickers outward. This will ensure proper alignment of the braces and keep your table from sagging. In the center and on the ends, place the U-channel over the bolts and fix into place.

3) Fasten the 31" braces to the tab on the center U-channel with the 1" bolts provided. Fasten the other end to the bottom tab on the leg with the 1" bolts. Fasten the shorter braces from the outer U-channel to the bottom tab on the leg and tighten nut

4) Flip over. Put on benches and fasten bolts through predrilled holes. Tighten all nuts firmly into place.